



# The Zero Downtime, Permanent Upgrade V-Belt

## Installation Instructions



LEGAL COMPLIANCE NOTICE: For more information regarding the products manufactured, distributed and sold by Fenner Drives and the compliance of such products with applicable domestic law, statutes, rules and regulations relating to human health and the environment (collectively "Environmental Laws"), including, without limitation, Proposition 65 as enacted by the State of California, please visit [www.fennerdrives.com](http://www.fennerdrives.com). If you are unable to access our website or if you have any further questions about the compliance of our products with Environmental Laws, you are encouraged to contact the Fenner Drives Health and Safety Manager at +1 (717) 665-2421.



US  
[www.fennerdrives.com](http://www.fennerdrives.com)  
TEL: 800-243-3374  
TEL: 717-665-2421  
FAX: 717-665-2649


UK  
[www.fennerdrives.com](http://www.fennerdrives.com)  
TEL: +44 (0) 870 757 7007  
TEL: +44 (0) 1924 482 470  
FAX: +44 (0) 1924 482 471

© 2012 Fenner Drives LB-36 04/2012

## English HOW TO MEASURE, ASSEMBLE & INSTALL

### I. How to Measure

Pull belt tight around pulleys to check hand tight length, overlapping the last two tabs with two holes in matching links as shown. Count the number of links and remove one link for every 24 of 3L, Z/10, A/4L and B/5L sections, and one link for every 20 of C and D sections. This gives the correct installed belt length and will ensure optimum belt tension when running.






Note: Every tenth link is designated with an arrow (→) (3L, Z/10, A/4L and B/5L only). For multiple belt drives, ensure that each belt has the same number of links.

**IMPORTANT — Turn belt INSIDE OUT (as shown) to ensure easy assembly and disassembly.**





### II. Disassembly

- Hold belt upside down. Bend back as far as possible; hold with one hand. Twist one tab 90° parallel with slot.
- Pull end of link over tab.
- Rotate belt end with tab 90°.
- Pull belt end through two links.




### III. Assembly

- Hold belt with tabs pointing outward.
- Place end tab through two links at once.
- Flex belt further and insert second tab through end link by twisting tab with thumb.
- Ensure tab returns to position across belt. Reverse belt so tabs run inside.



### IV. Installation

- Turn belt with tabs to the inside before installing.
- Determine direction of drive rotation.
- Belt must travel with tabs trailing or following the belt direction arrow (→).
- Fit belt in nearest groove of smaller pulley.
- Roll belt onto larger pulley, turning the drive slowly. Belt may seem very tight; this is ok; DO NOT JOG MOTOR.
- Check to see all tabs are still in their correct position and are not twisted out of alignment.
- For multiple belt drives, work belt from groove to groove. On particularly wide drives, it may be easier to install half the belts from the inboard side and half from the outboard.



Note: With drive ratios around 1:1, it may be necessary to add back one link to allow belts to be rolled on. This does not apply if using the Alternative Installation Method.

### V. Alternative Installation Method

- Set motor to mid-position of adjustment range and mark base clearly.
- Determine required belt length as in I.
- Push motor forward to minimum centre distance.
- Install belts as in IV.
- Pull motor back to previously marked mid-position.

### VI. Retensioning

Like all high performance V-belts, PowerTwist Plus V-Belts require the maintenance of correct drive tension to operate efficiently. Experience indicates that drive tension should be checked after 24 hours running at full load. A retension may be necessary depending on the severity of the drive. Any initial belt stretch is then taken up. Subsequently, belt tension should be checked periodically and adjusted when necessary.

**View the PowerTwist Plus Installation video at:  
[www.youtube.com/FennerDrives](http://www.youtube.com/FennerDrives)**